

Futaba

7 SERIES RECEIVER GUIDE Know your model numbers

R7008SB

PRODUCT

R = Receiver

SERIES

First number is the series

GAIN

Second number is the aerial gain

0 or **2**
= Normal gain

1 or **3**
= High gain

CHANNELS

Third and fourth number is the number of PWM channels

PROTOCOL

Last letters is the protocol



FIND YOUR LOCAL STOCKIST AT FUTABA.UK

Last updated 1st November 2024 - Rev 1.0